

VFlash Software Downloads


VFlash Software Updates are currently only available via the VFlash web interface.

Access VFlash web interface for the machine that requires an update.

Login as either an Administrator or Super Administrator.

Proceed to the Software Updates Page.

Make sure "Automatic Updates" is turned on. See the example below.



The screenshot shows a web interface titled "Software Update Configuration". Below the title, there is a paragraph of text: "Alter schedule and behavior of the software update by changing the sentence below via clicking on the und and typing a start date." Below this text, there is a form with the following text: "Do check for software updates every" followed by a dropdown menu showing "day", then "starting" followed by a text input field containing "{enter starting date here}", and finally "and do automatic machine is idle." The text "Do" and "do" are underlined, suggesting they are clickable links.

If any Software Updates are currently available, click the update link and the update will begin.